

Fitting Instructions #TRC4301IS

Volkswagen

Sway Bar Link Assembly

Directional references (left, right, front, rear) are always with reference to the driving direction.

Please note that the sway bar assembly is not adjusted and lock nuts are loose.

- Remove [OE] sway bar link pin assembly;
- Measure the length of the [OE] link measuring from centre of ball end to centre of ball end;
- Adjust the **TRC4301** sway bar link to the same length as the [OE] assembly;
- Referring to the Right Hand Side of the vehicle the [OE] link pin is fitted to the **Rear** of the bracket, when fitting **TRC4301** fit the ball end to the **Front** side of the bracket as shown in the image below;



As fitted from factory.
Right Hand Side



Refit to front of bracket to
clear drive shaft.
Right Hand Side

- Referring now to the Left Hand Side the ball end is fitted to the front side of the bracket this must stay the same and fit TRC4301 with Drive Shaft Clearance Extender;



TRC4301 Extender to clear Drive Shaft
Left Hand Side

- After installation to vehicle, tension ball end nuts to manufacture's specification, after tensioning a full nut must be seen. Also, tighten lock nuts;

Note that over tightening ball end nuts will damage the thread.

- Washers are supplied to be used where necessary.

