



## Audi B7 Upgraded Air Scoop Installation Instructions - ES3544051



Thank you for purchasing our new ECS Tuning Upgraded Intake Air Scoop, we appreciate your business!



### Features:

- Slotted mounting holes for easy installation.



### Benefits:

- Wider, longer scoop serves as a better/larger guide for incoming air.
- Completely hidden installation.
- Perfectly compliments our ECS Intake Systems.

## Section 1: Installing the Upgraded Intake Air Scoop

- Step 1**
- Remove the front bumper cover and locate the air scoop hole in the RH side of the core support (highlighted in **YELLOW** in the photo below).
- Step 2**
- Hold the upgraded air scoop in place over the core support with a gap of approximately 19mm ( $\frac{3}{4}$ " ) between the LH side of the scoop and the core support (**BLUE** lines and text in the photo below).
  - Once you've determined the mounting location, mark where the core support where the air scoop mounting holes are located. Drill a  $\frac{1}{4}$ " hole in the core support for each mounting screw.
    - USE CAUTION HERE**, do not drill through the radiator during this step.
- Step 3**
- Install one of the speed nuts onto each air scoop mounting location in the core support.
- Step 4**
- Install the air scoop into place using the supplied M6x12mm screws and M6 flat washers. Tighten the screws until snug.

