VW MK7 Carbon Fiber Steering Wheel Overlay Installation Overview - Click HERE to Shop

Skill Level 1 - Easy

1. Start by thoroughly cleaning and drying the mounting surface of the steering wheel.
2. Remove the red backing strip from each double-sided tape strip as shown.
3. Starting at the bottom, slide the overlay into place ensuring the lip slides underneath the airbag as shown.
4. Ensure that the overlay is properly oriented then firmly push down along the entire mounting area to ensure that the tape fully adheres to the steering wheel.

Congratulations, your installation is complete!









Proper service and repair procedures are vital to the safe, reliable operation of all motor vehicles as well as the personal safety of those performing the repairs. Standard safety procedures and precautions (including use of safety goggles and proper tools and equipment) should be followed at all times to eliminate the possibility of personal injury or improper service which could damage the vehicle or compromise its safety.