

TMS HP HFM kit TEN9989HFM

Parts list for kit:

- HFM
- Wiring harness
- Stainless steel bracket
- 6mm bolt with wave washer

Directions:

Step one remove stock air box.

Locate the mount that is welded on to the driver side shock tower.

Attach the wiring harness and bracket with the 6mm bolt and washer to the upper bolt hole on the shock tower mount. Make sure the wiring is facing the front of the car.

Plug the HFM engine harness into the TMS wiring harness.

Install EURO HFM intake kit with supplied HFM (See instructions supplied with intake kit.)

Plug TMS wiring harness into HP HFM

