



P3CARS.COM
PRECISION • PASSION • PERFORMANCE

Please download the latest copy of this document from www.p3cars.com/install

Audi 8v S3/A3



1 Take your VIDI out of the packaging. Set aside.



2 Apply pressure in the central clip holding the vent barrel inner vent to the out vent body housing.



3 Pull inner vent housing out of outer vent housing.



4 Set aside inner vent housing.

WARRANTY & LIABILITY:

Neither P3 Cars, nor its dealers or agents shall be liable in any way, for any damage, loss, injury or other claims, resulting from the installation or use of this product. By purchasing or installing this product, you assume all liability of any kind connected with the use and/or application of this product. If you are unsure that you can safely install and use this product, consult a qualified installer or mechanic. The warranty on this product covers only the product itself for a period of 6 months from the date of purchase, and it will be at our discretion to repair or replace the affected parts. No user serviceable parts inside. Warranty will be voided if product shows physical damage.



5 Insert VIDI cable between outer housing wall and far upright as shown.




6 Insert VIDI housing central clip into center clip housing.



P3CARS.COM
PRECISION • PASSION • PERFORMANCE

Please download the latest
copy of this document from
www.p3cars.com/install



You are now ready to enjoy your p3
cars VIDI!

WARRANTY & LIABILITY:

Neither P3 Cars, nor its dealers or agents shall be liable in any way, for any damage, loss, injury or other claims, resulting from the installation or use of this product. By purchasing or installing this product, you assume all liability of any kind connected with the use and/or application of this product. If you are unsure that you can safely install and use this product, consult a qualified installer or mechanic. The warranty on this product covers only the product itself for a period of 6 months from the date of purchase, and it will be at our discretion to repair or replace the affected parts. No user serviceable parts inside. Warranty will be voided if product shows physical damage.

